

0914-2d


0914-2f




0914-212
REAR DOOR LATCH AND LOCK ACTUATOR (LH)



0914-213
REAR DOOR LATCH AND LOCK ACTUATOR (RH)



Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.


REAR DOOR LATCH AND LOCK ACTUATOR (LH)
0914-212
(DR4)[LIGHT GRAY]
(R)-(DR4)
C-17
C-18
(R)-(DR3)
(DR3)[LIGHT GRAY]
[4SD]
0914-213
REAR DOOR LATCH AND LOCK ACTUATOR (RH)
(DR4)[LIGHT GRAY]
(R)-(DR4)
C-17
0914-212
REAR DOOR LATCH AND LOCK ACTUATOR (LH)
C-18
(R)-(DR3)
(DR3)[LIGHT GRAY]
[5HB]
0914-213
REAR DOOR LATCH AND LOCK ACTUATOR (RH)
: REAR HARNESS
: REAR No.2 HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS