





0914-219
TRUNK LID OPENER SWITCH (INTERIOR)




0912-201A
POWER WINDOW MAIN SWITCH / POWER OUTER MIRROR SWITCH / DOOR LOCK SWITCH (RH)




0940-101B
BCM





0940-101C
BCM




Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.









: FRONT HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: INSTRUMENT PANEL HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS