





0918-1001
AUTO LEVELING CONTROL MODULE




0918-1002
AUTO LEVELING SENSOR



0918-305
FRONT COMBINATION LIGHT (LH) /
HEADLIGHT LEVELING ACTUATOR (LH)




(HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM)




(HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM)

0918-306
FRONT COMBINATION LIGHT (RH) /
HEADLIGHT LEVELING ACTUATOR (RH)




(HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM)




(HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM)


Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.



[4SD]

0918-1002
AUTO LEVELING SENSOR
[BLACK]






[BLACK]
AUTO LEVELING SENSOR
0918-1002

[5HB]

[DARK GRAY] ← HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM
[GRAY] ← HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM
FRONT COMBINATION LIGHT (RH) /
HEADLIGHT LEVELING ACTUATOR (RH)
0918-306




0918-1001
AUTO LEVELING CONTROL MODULE

[DARK GRAY] ← HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM
[GRAY] ← HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM
FRONT COMBINATION LIGHT (RH) /
HEADLIGHT LEVELING ACTUATOR (RH)
0918-306

[DARK GRAY] ← HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM
[GRAY] ← HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM
FRONT COMBINATION LIGHT (LH) /
HEADLIGHT LEVELING ACTUATOR (LH)
0918-305


RELAY AND FUSE BLOCK
(REFER TO 00F SECTION)
F-01



0918-305
FRONT COMBINATION LIGHT (LH) /
HEADLIGHT LEVELING ACTUATOR (LH)
[DARK GRAY] ← HEADLIGHT LED TYPE, WITH HEADLIGHT MANUAL LEVELING SYSTEM
[GRAY] ← HEADLIGHT BULB TYPE / WITHOUT HEADLIGHT MANUAL LEVELING SYSTEM

[SKYACTIV-G 1.3, 1.5]

RELAY AND FUSE BLOCK
(REFER TO 00F SECTION)
F-01



[SKYACTIV-D 1.5]

: FRONT HARNESS
: ENGINE HARNESS
ENGINE No.2 HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: INSTRUMENT PANEL HARNESS
: EMISSION HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS