


0918-504
LIGHT SWITCH / FOG LIGHT SWITCH / TURN SWITCH

K	J	I	H	G	F	E	D	C	B	A


0919-105
AUTO LIGHT SENSOR / RAIN SENSOR


P	✳	B	V
D	C	B	A


0940-101C
BCM


3W	3U	3S	3Q	3O	3M	3K	3I	3G	3E	3C	3A
BR	G	V	G	LG	G	GY	R	T	P	W	L
V	GY	P	Y	✳	BR	L	GY	V	SB	L	R
3X	3V	3T	3R	3P	3N	3L	3J	3H	3F	3D	3B

Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.









: FRONT HARNESS
: REAR HARNESS
: REAR No.2 HARNESS
: INSTRUMENT PANEL HARNESS
: DOOR HARNESS
: INTERIOR LIGHT HARNESS
INTERIOR LIGHT No.2 HARNESS