




0922-201
CLOCK SPRING



0922-202
CRUISE CONTROL SWITCH /
STEERING SWITCH /
CLOCK SPRING



0922-203A
HORN




0922-203B
HORN




0922-204
HORN SWITCH




0940-101C
BCM




Refer to 00F section for the FUSE BOX, 00C section for the PCM CONNECTOR and COMMON CONNECTOR LIST.




[SKYACTIV-G 1.3, 1.5]



[SKYACTIV-D 1.5]





: FRONT HARNESS
: ENGINE HARNESS
ENGINE No.2 HARNESS
: REAR HARNESS
: INSTRUMENT PANEL HARNESS
: EMISSION HARNESS