ON-BOARD DIAGNOSTIC SYSTEM ACTIVE COMMAND MODES FUNCTION [SKYACTIV-D 1.5]

id0102q2105400

Note
- Simulation items on parts which are not equipped to the vehicle do not operate.
- When the engine conditions and the other conditions have been met, the simulation item can be operated.

- The simulation items are shown below.

Simulation item table

Item	Applicable component	Unit/Condition	Engine condition	Other condition
ACCS	A/C relay	Off/On	• Under the following conditions: — Ignition is switched ON (engine off)	Not applicable
ARPMDES	Target engine speed	RPM	• Under the following conditions: — Idle	Not applicable
EWP*3	Electric water pump	%	• Under the following conditions: — Ignition is switched ON (engine off) — Idle	Not applicable
CCV_DSD*2	Desired coolant control valve	°	• Under the following conditions: — Ignition is switched ON (engine off) — Idle — Racing (not idle)	Not applicable
EXHSHUT_DSD	Exhaust shutter valve desired	%	• Under the following conditions: — Ignition is switched ON (engine off) — Idle	Not applicable
FAN_DUTY*4	Fan control module duty cycle	%	• Under the following conditions: — Ignition is switched ON (engine off) — Idle	Not applicable
HPEGR_DSD	HP-EGR control valve desired	%	• Under the following conditions: — Ignition is switched ON (engine off)	Not applicable
INJ_1*1	Fuel injector No.1	OFF	• Under the following conditions: — Idle	• Under the following conditions: — Vehicle stopped
INJ_2*1	Fuel injector No.2	OFF	• Under the following conditions: — Idle	• Under the following conditions: — Vehicle stopped
INJ_3*1	Fuel injector No.3	OFF	• Under the following conditions: — Idle	• Under the following conditions: — Vehicle stopped
INJ_4*1	Fuel injector No.4	OFF	• Under the following conditions: — Idle	• Under the following conditions: — Vehicle stopped
ISV_DSD	Intake shutter valve control desired value	°	• Under the following conditions: — Ignition is switched ON (engine off)	Not applicable
LPEGR_DSD	LP-EGR control valve desired	%	• Under the following conditions: — Ignition is switched ON (engine off) — Idle	Not applicable

Item	Applicable component	Unit/Condition	Engine condition	Other condition
VGTURB_DSD	Turbocharger with variable turbine geometry position desired	%	• Under the following conditions: — Idle	Not applicable

*1 : By using these items, freeze frame data may be overwritten when a DTC is detected. Obtain the freeze frame data before using these items. In addition, clear the DTC if a DTC is detected.

*2 : Changes in 10 steps from 10 degrees up to 215 degrees.

*3 : Changes in 2 steps of 0 percent and 95 percent.

*4 : Changes in 10 % increments up to 80 % from 0 %.