AFTER REPAIR PROCEDURE [SKYACTIV-D 1.5]

id0102q2801100

1. Switch the ignition off.
2. Connect the M-MDS to the DLC-2.
3. Switch the ignition ON (engine off).