CAMSHAFT [SKYACTIV-D 1.5]


id0110q2001400

Purpose, Function

- The camshaft is rotated by receiving the rotation force of the crankshaft via the timing chain. The valve is opened and closed according to the cam shape at this time.


Construction

- The camshaft is located on the cylinder head.
- The cam has been induction hardened. As a result, resistance to abrasion has been enhanced.



am2zzn00002713

Valve timing



am2zzn00002714

Valve timing	IN	Open	BTDC (°)	3
		Closed	ABDC (°)	25
	EX	Open	BBDC (°)	40
		Closed	ATDC (°)	8