CYLINDER HEAD GASKET [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0110q3000300

Purpose, Function

- The cylinder head gasket is installed between the cylinder head and cylinder block to prevent leakage of air-fuel mixture, combustion gas, engine oil, and engine coolant.

Construction

- A three-layer type metal gasket has been adopted for the cylinder head gasket.



am2zzn00003025