
OIL FILTER [SKYACTIV-D 1.5]

id0111q2002200


Purpose, Function
- Engine oil is filtered by passing engine oil through the oil filter element.

Construction
- The oil filter is located on the left side surface of the cylinder block.
- A spin-on type (full-flow type) oil filter has been adopted.
- A full-flow type oil filter has been adopted.



am2zzn00003198

- If the oil filter element becomes clogged, the oil filter has a by-pass valve designed as a detour.



am2zzn00003199