OIL PAN [SKYACTIV-D 1.5]


id0111q2002300

Purpose, Function

- The engine oil required for lubrication in the engine accumulates in the oil pan.

Construction

- The oil pan is located under the cylinder block.
- Silicone sealant with excellent sealing has been adopted for the oil pan gasket.



am2zzn00003200