OIL COOLER [SKYACTIV-D 1.5]


id0111q2101100

Purpose, Function

- The oil cooler routes engine oil and engine coolant through the interior and disperses the engine oil heat using the engine coolant. As a result, the oil temperature is maintained properly to reduce the engine oil deterioration.


Construction

- The oil cooler is located on the left side of the engine block.



am2zzn00003213

- A water-cooled, 8-layer-type oil cooler has been adopted.



am2zzn00003214