
LUBRICATION SYSTEM LOCATION INDEX [SKYACTIV-D 1.5]

id0111q2800100



am2zzw00011156

1	Dipstick (See ENGINE OIL LEVEL INSPECTION [SKYACTIV-D 1.5].) (See ENGINE OIL REPLACEMENT [SKYACTIV-D 1.5].)
2	Engine oil temperature sensor/engine oil pressure sensor (See OIL PRESSURE INSPECTION [SKYACTIV-D 1.5].)
3	Oil cooler (See OIL COOLER REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
4	Engine oil solenoid valve (See ENGINE OIL SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) (See ENGINE OIL SOLENOID VALVE INSPECTION [SKYACTIV-D 1.5].)
5	Oil filter (See OIL FILTER REPLACEMENT [SKYACTIV-D 1.5].)
6	Oil pump (See OIL PUMP REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
7	Oil strainer (See OIL PUMP REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
8	Oil pan (See OIL PAN REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)