OIL PUMP [SKYACTIV-G 1.3, SKYACTIV-G 1.5 (WITH 4-1 EXHAUST SYSTEM)]

id0111q30025q4

Purpose, Function

- The oil pump suctions the engine oil in the oil pan through the oil strainer and pumps engine oil into the engine.

Construen