
COOLING SYSTEM LOCATION INDEX [SKYACTIV-D 1.5]

id0112q2800100



adejjw00012988

1	Water-cooled charge air cooler reserve tank cap (See WATER-COOLED CHARGE AIR COOLER RESERVE TANK CAP INSPECTION [SKYACTIV-D 1.5].)
2	Water-cooled charge air cooler reserve tank (See WATER-COOLED CHARGE AIR COOLER COOLANT LEVEL INSPECTION [SKYACTIV-D 1.5].) (See WATER-COOLED CHARGE AIR COOLER RESERVE TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
3	Water pump (See WATER PUMP REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
4	Coolant control valve (See COOLANT CONTROL VALVE REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) (See COOLANT CONTROL VALVE INSPECTION [SKYACTIV-D 1.5].)
5	Electric water pump (See ELECTRIC WATER PUMP REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) (See ELECTRIC WATER PUMP INSPECTION [SKYACTIV-D 1.5].)
6	Coolant reserve tank (See ENGINE COOLANT LEVEL INSPECTION [SKYACTIV-D 1.5].) (See COOLANT RESERVE TANK REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
7	Cooling fan motor (See COOLING FAN MOTOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].) (See COOLING FAN MOTOR INSPECTION [SKYACTIV-D 1.5].)
8	Fan control module (See FAN CONTROL MODULE INSPECTION [SKYACTIV-D 1.5].)
9	Radiator (See ENGINE COOLANT PROTECTION INSPECTION [SKYACTIV-D 1.5].) (See ENGINE COOLANT REPLACEMENT [SKYACTIV-D 1.5].) (See WATER-COOLED CHARGE AIR COOLER COOLANT REPLACEMENT [SKYACTIV-D 1.5].) (See ENGINE COOLANT LEAKAGE INSPECTION [SKYACTIV-D 1.5].) (See WATER-COOLED CHARGE AIR COOLER COOLANT LEAKAGE INSPECTION [SKYACTIV-D 1.5].) (See RADIATOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)
10	Cooling system cap (See COOLING SYSTEM CAP INSPECTION [SKYACTIV-D 1.5].)