RESONANCE CHAMBER [SKYACTIV-G 1.5]


id0113q10034zf

Purpose, function

- Pulsation of intake air is controlled and intake air noise is reduced by adding an intake air passage.

Construction

- The resonance chamber is installed to fresh-air duct.



am2zzn00003123

cardiagn.com