AIR CLEANER [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0113q1003500

Purpose, Function

- The air cleaner prevents engine internal damage caused by the penetration of dust or foreign matter.


Construction

- The air cleaner is located in front of the vehicle battery.



am2zzn00003124


- The air cleaner consists of the air cleaner case, air cleaner cover, and air cleaner element.



am2zzn00003125

cardiagn.com

- Non-woven fabric (dry type) air cleaner element has been adopted to remove dust and foreign material in the intake air.



am2zzn00003126

cardiagn.com