VACUUM PUMP [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0113q1003800

Purpose, Function

- The vacuum pump ensures vacuum required for braking force to compensate for the decrease in intake manifold vacuum applied to the power brake unit caused by the retard intake valve closing.


Construction

- The vacuum pump is located on the engine (rear).



am2zzn00003129

- For smooth vane rotation, a single-vane type vacuum pump equipped with a lubrication passage has been adopted for circulating a part of the engine oil.




am2zzn00003130

Operation


- Because the vacuum pump is directly engaged with the exhaust camshaft, the vane in the vacuum pump rotates together with the exhaust camshaft, and the vacuum chamber is expanded and vacuum is generated.

cardiagn.com




am2zzn00003131

Vacuum generation mechanism



am2zzn00003591

Intake air and engine oil exhaust mechanism



am2zzn00003132

cardiagn.com