FRESH-AIR DUCT [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0113q1675400

Purpose, Function

- The fresh-air duct conducts fresh air into the engine compartment.
- Increases air density by taking fresh air, which is cooler than the engine compartment, to enhance the charging efficiency, ensuring the combustion stability.

Construction

- The fresh-air duct is located on the air cleaner.



am2zzn00003135

cardiagn.com