INTAKE MANIFOLD VACUUM INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0113q1801500

1. Disconnect the evaporative hose (purge solenoid valve side) connecting the intake manifold and the purge solenoid valve, then install the vacuum gauge. (See PURGE SOLENOID VALVE REMOVAL/INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
2. Verify that the intake air hoses are installed securely.
3. Warm up the engine.
4. Measure the intake manifold vacuum while idling (no load) using the vacuum gauge.
   - If not within the specification, perform the following inspections.
     - — Compression pressure (See COMPRESSION INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
     - — Check valve (See CHECK VALVE INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
     - — Air suction
       - Installation areas of each vacuum hose
       - Evaporative hose connecting part
       - Installation area of throttle body
       - Installation area of fuel injector
       - Installation area of PCV valve
       - Installation area of intake manifold

Standard
Approx. –60.0 kPa {–450.0 mmHg, –17.7 inHg}