## AIR CLEANER [SKYACTIV-D 1.5]


id0113q2003500

### Purpose, Function

- The air cleaner prevents engine internal damage caused by the penetration of dust or foreign matter.


### Construction

- The air cleaner is located in front of the vehicle battery.





am2zzn00003243

- The air cleaner consists of the air cleaner case, air cleaner cover, and air cleaner element.




am2zzn00003244

- Non-woven fabric (dry type) air cleaner element has been adopted to remove dust and foreign material in the intake air.




am2zzn00003245