INTAKE MANIFOLD [SKYACTIV-D 1.5]


id0113q2003700

Purpose, Function

- The intake manifold distributes intake air to each cylinder evenly.
- The combustion efficiency and performance of the engine is optimized by distributing the intake air to each cylinder.

Construction

- The intake manifold is located on the cylinder head.



am2zzn00003246