## FRESH-AIR DUCT [SKYACTIV-D 1.5]


id0113q2675400

### Purpose, Function

- The fresh-air duct conducts fresh air into the engine compartment.
- Increases air density by taking fresh air, which is cooler than the engine compartment, to enhance the charging efficiency, ensuring the combustion stability.

### Construction

- The fresh-air duct is located on the air cleaner.




am2zzn00003252

cardiagn.com