GLOW PLUG [SKYACTIV-D 1.5]


id0113q2706200

Purpose, Function

- The glow plug raises the compression temperature by preheating the inside of the combustion chamber.


Construction

- The glow plugs are located on the cylinder heads.



am2zzn00003256


- Quick warming-type ceramic glow plugs have been adopted which reduce the time required to start the engine by quickly increasing the temperature.



ac5wzn00000179

Operation

- The glow plugs generate heat by the power supplied from the glow control module.



am2zzn00003257