FUEL TANK [SKYACTIV-D 1.5]


id0114q2104100

Purpose, Function

- The fuel tank stores fuel safely.


Construction

- The fuel tank is located under the rear seat.



am2zzn00003276

- The fuel tank is made of plastic.
- The following parts are integrated in the fuel tank.
- Non-return valve
  (See NON-RETURN VALVE [SKYACTIV-D 1.5].)
- Rollover valve
  (See ROLLOVER VALVE [SKYACTIV-D 1.5].)



am2zzn00003277