FUEL FILTER WATER DRAINING [SKYACTIV-D 1.5]


id0114q2777600

Note
- When the drain plug is loosened for draining, the drain plug O-ring can be reused.

1. Remove the fuel tank side cover. (See FUEL TANK SIDE COVER REMOVAL/INSTALLATION.)

Note
- If the water drainage is poor, disconnect the quick release connector shown in the figure. (See QUICK RELEASE CONNECTOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)

2. Loosen the drain plug and drain the water.
3. Tighten the drain plug sufficiently.



am2zzw00012091

cardiagn.com