MAIN SILENCER [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0115q1101000

Purpose, Function

- The main silencer reduces exhaust noise.


Construction

- The main silencer is located at the rear of the vehicle, under the trunk compartment.



am2zzn00003888

- The main silencer consists of the filter, stuffing, stuffing holder and set plate.



am2zzn00003886