EXHAUST SYSTEM INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0115q1800100

1. Start the engine and inspect each exhaust system component for exhaust gas leakage.
   - If there is leakage, repair or replace the appropriate component. (See EXHAUST SYSTEM REMOVAL/ INSTALLATION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)