PRESILENCER [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0115q1808800

Purpose, Function

- The presilencer reduces exhaust noise.

Construction


- The presilencer is located behind the catalytic converter (TWC).



am2zzn00003887


- The presilencer consists of the filters, stuffing and wool-stainless.

SKYACTIV-G 1.3



am2zzn00003166

SKYACTIV-G 1.5



am2uun00001119