CHARCOAL CANISTER [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0116q1121900

Purpose, Function

- The charcoal canister absorbs the evaporative gas generated inside the fuel tank to prevent release of the gas into the atmosphere.


Construction

- The charcoal canister is located near the fuel tank.



am2zzn00003178


- The charcoal canister has activated charcoal to absorb evaporative gas.



am2zzn00003179

Operation

- When the purge solenoid valve is open, evaporative gas, which is absorbed by the activated charcoal, is released by the intake manifold vacuum and the gas flows to the intake manifold.



am2zzn00003180