ROLLOVER VALVE [SKYACTIV-G 1.3, SKYACTIV-G 1.5]


id0116q1122900

Purpose, Function

- The rollover valve prevents fuel flow into the evaporative gas passage during sudden cornering or vehicle rollover.


Construction

- The rollover valve is built into the fuel tank.



am2zzn00003181


- The rollover valve consists of a float, O-ring and spring.



am2zzn00003182

Operation

- The rollover valve utilizes a combination of float weight, spring force, and buoyancy. When the float is immersed in the fuel, the float (valve) closes to block the sealing surface of the passage.



am2zzn00003183