
## POSITIVE CRANKCASE VENTILATION (PCV) SYSTEM [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0116q1148900

### Purpose, Outline

- The positive crankcase ventilation system prevents release of blow-by gas (unburnt gas) into the atmosphere.
- The intake manifold vacuum introduces blow-by gas to the intake manifold via the PCV valve and the ventilation hose.

### System Diagram




am2zzn00003184

### Structure

- The positive crankcase ventilation system consists of the following parts:

| Part name | Reference |
|---|---|
| PCV valve | (See POSITIVE CRANKCASE VENTILATION (PCV) VALVE [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) |
| Ventilation hose | — |