EMISSION SYSTEM [SKYACTIV-D 1.5]


id0116q2110100

Outline

- Diesel particulate elimination equipment (Diesel Particulate Filter) has been adopted which eliminates PM from the exhaust gas.
- By recirculating the exhaust gas after it passes the catalytic converter, load on the turbocharger system is reduced and high environmental performance is achieved.


Structural View

Engine compartment side




am2zzn00003302

Exhaust system side




am2zzn00003303

Fuel tank side



am2zzn00003304


System Diagram



am2zzn00003305


Vacuum Hose Routing Diagram

L.H.D.



am2zzn00003918

R.H.D.



am2zzn00003919

Structure

- The emission system consists of the following parts:

Part/System name		Reference
Exhaust gas purification system (See EXHAUST GAS PURIFICATION SYSTEM [SKYACTIV-D 1.5].)	Catalytic converter	(See CATALYTIC CONVERTER [SKYACTIV-D 1.5].)
Exhaust gas recirculation system (See EXHAUST GAS RECIRCULATION SYSTEM [SKYACTIV-D 1.5].)	Intake shutter valve	(See INTAKE SHUTTER VALVE [SKYACTIV-D 1.5].)
	HP-EGR control valve	(See HP-EGR CONTROL VALVE [SKYACTIV-D 1.5].)
	exhaust shutter valve	(See EXHAUST SHUTTER VALVE [SKYACTIV-D 1.5].)
	LP-EGR control valve	(See LP-EGR CONTROL VALVE [SKYACTIV-D 1.5].)
	EGR cooler	(See EGR COOLER [SKYACTIV-D 1.5].)
	EGR pipe	(See EGR PIPE [SKYACTIV-D 1.5].)
Fuel-filler cap		(See FUEL-FILLER CAP [SKYACTIV-D 1.5].)
Rollover valve		(See ROLLOVER VALVE [SKYACTIV-D 1.5].)
Check valve		(See CHECK VALVE [SKYACTIV-D 1.5].)

Part/System name	Reference
Evaporative chamber	(See EVAPORATIVE CHAMBER [SKYACTIV-D 1.5].)
Diesel particulate filter	(See DIESEL PARTICULATE FILTER [SKYACTIV-D 1.5].)