## CATALYTIC CONVERTER [SKYACTIV-D 1.5]


id0116q2814400

### Purpose, Function

- The catalytic converter (oxidation catalyst) utilizes chemical reactions to purify contaminants in the exhaust gas.

### Construction

- The catalytic converter is located behind the engine.




am2zzn00003339

### Operation

- The catalytic converter (oxidation catalyst) converts the noxious carbon monoxide and hydrocarbon in the exhaust gas to non-noxious carbon dioxide and water.
  **Oxidization process**
  $O_2 + HC + CO = CO_2 + H_2O$
- For details on the catalytic converter (oxidation catalyst), refer to the DIESEL PARTICULATE FILTER. (See DIESEL PARTICULATE FILTER [SKYACTIV-D 1.5].)