GENERATOR INSPECTION [WITHOUTam2w00012337

Charging System Warning Light

1. Verify that the battery is fully charged. (See BATTERY INSPECTION.)
2. Verify that the assembly condition of the drive belt is normal. (S

Terminal 1A:13~~15~~ V
Terminal 2A:Approx. 3~~8~~ V
Terminal 2B:Turn the electrical loads (such as

Generator current inspection

Note

- Since the charging current decreases rapidly after starting the engine, carry out the following procedure quickly, and read the maximum current value.

Brush