
CHARGING SYSTEM [WITHOUT i-ELOOP (SKYACTIV-D 1.5)]

id0117q61029j8

Note

- For location index of the generator, DC-DC converter (i-ELOOP), capacitor on vehicles with i-ELOOP, refer to the i-ELOOP section. (See i-ELOOP [i-ELOOP].)

Structural View



am2zzn00003342

Structure

- Consists of the following parts:

Battery	(See BATTERY [SKYACTIV-D 1.5].)
Charging system warning light	(See CHARGING SYSTEM WARNING LIGHT [SKYACTIV-D 1.5].)
DC-DC converter	(See DC-DC CONVERTER [WITHOUT i-ELOOP (SKYACTIV-D 1.5)].)
Generator	(See GENERATOR [WITHOUT i-ELOOP (SKYACTIV-D 1.5)].)