CRUISE MAIN INDICATOR LIGHT (AMBER), CRUISE SET INDICATOR LIGHT (GREEN) [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0120q1100500

Purpose/Function

Cruise main indicator light (amber)


- Illuminates while the cruise control system is in standby mode to inform the driver that the cruise control system is on standby.

Cruise set indicator light (green)

- Illuminates during the cruise control system operation to inform the driver that the cruise control system is operating.

Construction


- Built into the instrument cluster.



am2zzn00003582


Operation

- The illumination conditions for the cruise main indicator light (amber) and cruise set indicator light (green) are as follows:



am3zzn00003523

- The PCM sends a cruise main indicator light (amber) or cruise set indicator light (green) illumination request signal to the instrument cluster via CAN communication through the BCM.



am2zzn00003583

Fail-safe

- Not applicable