DRIVE SELECTION SWITCH [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0121a2000200

Purpose/Function

- The drive selection switch detects the switching operation of the drive selection.
- The drive selection switch signal sent to the instrument cluster.

Construction

- The drive selection swich is located shift panel.
- A toggle-type switch has b035 3w[tog)5 4 ad toopted for th035 drive selection switch.