- The PCM sends an i-stop warning light (amber) flashing/illumination request to the instrument cluster via CAN communication.