
i-stop INDICATOR ALARM [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0140q1300400

Purpose
- The i-stop indicator alarm alerts the user that the i-stop OFF switch is pressed.


Function
- When the i-stop OFF switch signal is received from the PCM, the instrument cluster sounds the i-stop indicator alarm.
- The i-stop indicator alarm sound pattern is as shown in the figure:



ac5wzn00001424

Construction
- The i-stop indicator alarm sounds using the buzzer built into the instrument cluster.

Operation
1. The instrument cluster receives (1) the i-stop OFF switch signal from the PCM.
2. The instrument cluster microcomputer turns on (2) the transistor based on the i-stop OFF switch signal.
3. When the transistor turns on, a ground circuit with the alarm is established and the alarm sounds (3).



am2zzn00003450

Fail-safe
- Not applicable