
POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5]

id0140q1889400

Voltage Inspection

1. Connect the **M-MDS** to the DLC-2.
2. Switch the ignition ON (engine off).
3. Verify that the power brake unit vacuum sensor output voltage (PID: BBP) is within the specification. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 1.3, SKYACTIV-G 1.5].) (See PCM INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)
   - If not as specified, replace the power brake unit vacuum sensor. (See POWER BRAKE UNIT VACUUM SENSOR INSPECTION [SKYACTIV-G 1.3, SKYACTIV-G 1.5].)

Specification (Reference)



am3zzw00013577