BAROMETRIC PRESSURE (BARO) SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 1.5]

id0140q2805600

Note
- Because the BARO sensor is integrated in the PCM, replacing the BARO sensor includes replacement of the PCM.

1. Remove the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 1.5].)