AIR FUEL RATIO (A/F) SENSOR [SKYACTIV-D 1.5]


id0140z5004800

Purpose/Function

- Detects the oxygen concentration (all-range air/fuel ratio) in the exhaust gas as basic information for mainly determining the EGR amount.
- Detects the oxygen concentration (all-range air/fuel ratio) in the exhaust gas and sends it to the PCM as an oxygen concentration (all-range air/fuel ratio) signal.

Construction


- Installed on the rear side of the catalytic converter.
- A zirconium element has been adopted as the detecting element for detecting the oxygen concentration (all-range air/fuel ratio).



am2zzn00003600


Operation

- Sends the signal, which fluctuates according to the oxygen concentration (all-range air/fuel ratio), to the PCM.



am2zzn00003601

A/F sensor characteristic



am2zzn00003602

Fail-safe

DTC No.	Fail-safe function
P0030:00	• Limits the engine torque. • Inhibits the EGR control. • Inhibits the auto DPF regeneration control. • Inhibits the compulsory DPF regeneration control. • Inhibits engine-stop by operating the i-stop function.
P0130:00	
P0131:00	
P0132:00	
P0134:00	
P2A00:00	