CAMSHAFT POSITION (CMP) SENSOR [SKYACTIV-D 1.5]


id0140z5006700

Purpose/Function

- Detects the camshaft speed as basic information for mainly determining the fuel injection timing.
- Detects the camshaft speed and sends it to the PCM as a CMP signal.

Construction


- Installed on the cylinder head.
- A MR (Magnetic Resistance) element has been adopted as the detecting element for detecting the camshaft speed.



am2zzn00003615


Operation

- Sends the signal, which fluctuates according to the camshaft speed, to the PCM.



am2zzn00003616

CMP sensor characteristic



adejjn00004115

Fail-safe

DTC No.	Fail-safe function
P0016:00	• Inhibits engine-stop by operating the i-stop function. • PCM restricts engine-transaxle integration control. (ATX)