
NEUTRAL SWITCH [SKYACTIV-D 1.5]

id0140z5008100


Purpose/Function
- Detects the neutral position of the shift lever.

Construction
- Installed to the manual transaxle.
- An ON/OFF type switch has been adopted.




am2zzn00003633

Operation
- Sends the neutral switch on/off signal to the PCM.



am2zzn00003634

- The contact point is on when in neutral to output voltage and off when not in neutral.



am2zzn00003635

Fail-safe

DTC No.	Fail-safe function
P0850:00	• Inhibits engine-stop by operating the i-stop function.