ENGINE OIL TEMPERATURE SENSOR [SKYACTIV-D 1.5]


id0140z5256900

Purpose/Function

- Detects the engine oil temperature as basic information for mainly diesel particulate filter regeneration control.
- Detects the engine oil temperature and sends it to the PCM as an engine oil temperature signal.

Construction


- Installed on the cylinder block.
- A thermistor has been adopted as the detecting element for detecting the engine oil temperature.
- The engine oil temperature sensor is integrated with the engine oil pressure sensor.



am2zzn00003688


Operation

- Sends the signal, which fluctuates according to the engine oil temperature, to the PCM.



am2zzn00003689

Engine oil temperature sensor characteristic



am2zzn00003690

Fail-safe

- Not applicable