BLOW-BY-HEATER RELAY [SKYACTIV-D 1.5]

id0140z5258700

Purpose/Function

- Supplies power to blow-by heater.
- Supplies battery voltage to blow-by heater based on the signals from the PCM.

Construction