TIRE PRESSURE MONITORING SYSTEM SET SWITCH


id021200203000

Purpose

- The tire pressure monitoring system set switch is used to initialize the tire pressure monitoring system.

Construction, Operation

- The tire pressure monitoring system set switch is installed to the dashboard.
- The tire pressure monitoring system set switch has adopted a monitoring type switch.
- The tire pressure monitoring system set switch sends a tire pressure monitoring system initialization signal to the instrument cluster.



am3uun00003236

Fail-safe

DTC	Fail-safe
C1031:35	• Illuminates the tire pressure monitoring system warning light. • Inhibits the TPMS control.