
INSTANT MOBILITY SYSTEM

id021200629800

- An instant mobility system is equipped for temporary repair of a puncture.
- Compared to equipping a spare tire, the vehicle weight is reduced and the fuel economy is improved.
- The instant mobility system is located in trunk compartment and includes the following:



am2zzn00001792

  - — Repair agent
  - — Repair agent filler hose
  - — Air compressor
  - — Tire valve core
  - — Tire valve core tool
  - — Instruction manual
  - — Speed limit label
- Because the instant mobility system requires less space compared to a spare tire, utility of the trunk compartment can be enhanced.

Operation

- If the repair agent is injected into a tire using the air compressor, liquid rubber, one of the ingredients of the repair agent, soak into the punctured area and solidify, allowing temporal driving.
- Use the accessory socket (DC12V) for the power source of the air compressor.

Note

- The expiration date of the repair agent is printed on the repair agent bottle. Do not use the repair agent if it has passed the expiration date.
- When disposing of the repair agent, commission an industrial waste disposal contractor.