SIMULATION TABLE [ABS HU/CM]

id040260886600

Simulation item	Output part	Operation	Operating condition
PMP_MT_SP	Pump motor	Off/On	Switch the ignition ON
V_INLET_LF	LF inlet solenoid valve		
V_INLET_LR	LR inlet solenoid valve		
V_INLET_RF	RF inlet solenoid valve		
V_INLET_RR	RR inlet solenoid valve		
V_OUTLET_LF	LF outlet solenoid valve		
V_OUTLET_LR	LR outlet solenoid valve		
V_OUTLET_RF	RF outlet solenoid valve		
V_OUTLET_RR	RR outlet solenoid valve		